



CLX-150La PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	11001752	MAIN BODY ASSY	703	17030011	WORM SHAFT GUARD
105	11050006	WORM SHAFT BUSHING	704	17040042	LINE GUIDE SUPPORT BAR
105-1	11050007	WORM SHAFT BUSHING	705	17050011	TRANSMISSION GEAR
117	11170012	RETAINER NUT	706	17060003	TRANSMISSION GEAR
200	12001959	HANDLE SIDE PLATE	707	17070009	TRANSMISSION GEAR
201	12010011	ANTI-RE PAWL	710	17100040	LINE GUIDE ASSY.
207	12070098	HOLDED PLATE	712	17120032	WORM SHAFT
211	12110009	ANTI-RE PAWL PIN	713	17130002	LINE GUIDE PAWL CAP
215	12150015	HOLD PLATE BUSHING	715	17150009	LINE GUIDE PAWL
215-1	12150029	HOLD PLATE BUSHING	800	18000008	CLUTCH SHAFT
216	12160001	ANTI-RE PAWL SPRING	801	18010001	CLUTCH SPRING
300	13001051	VICE SIDE PLATE	802	18020001	CLUTCH BAR
302	13020002	WASHER	804	18040013	CLUTCH CAM SLIDER
302-1	13020005	BUSHING	805	18050002	PINION GEAR YOKE
302-3	13020017	WASHER	806	18060003	YOKE SPRING
303	13030042	CLICK BUTTON	29000001	29000001	E RETAINER
304	13040001	CLICK PAWL	29000006	29000006	C RETAINER
305	13050007	CLICK PAWL SPRING	0920283	0920283	WASHER
400	14000467	SPOOL ASSY.	0920114	0920114	WASHER
401	14010026	SPOOL CLICK GEAR	0920151	0920151	WASHER
500	15000190	HANDLE ASSY.	0920076	0920076	WASHER
516	15160002	HANDLE NUT RETAINER	0920291	0920291	WASHER
600	16000038	CAST CONTROL CAP	0920332	0920332	WASHER
609	16090003	DRAG SPRING WASHER	0920066	0920066	WASHER
610	16100017	DRAG WASHER	0930298	0930298	SCREW
610-1	16100030	DRAG WASHER	0930058	0930058	SCREW
611	16110005	EARED WASHER	0930210	0930210	SCREW
612	16120027	KEY WASHER	0930732	0930732	SCREW
614	16140003	DRAG WASHER	0930609	0930609	SCREW
615	16150009	STAR DARG	0930196	0930196	SCREW
617	16170008	DRIVE GEAR SHAFT BUSHING	0930219	0930219	SCREW
617-1	16170018	DRIVE GEAR SHAFT BUSHING	0930202	0930202	SCREW
618	16180002	WASHER	0930575	0930575	SCREW
700	17000205	DRIVE GEAR	0930226	0930226	SCREW
701	17010278	DRIVE GEAR SHAFT ASSY	0940025	0940025	O RING
702	17020310	PINION GEAR ASSY.			