



SLR-30II PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	11001519	MAIN BODY	607	16070053	PINION GUARD
101	11010029	BODY LOGO	608	16080004	DRAG WASHER RETAINER
102	11020015	BODY FOOT	609	16090012	SPRING WASHER
103	11030003	BODY FOOT SCREW	611	16110050	EARED WASHER
104	11040001	BODY FOOT NUT	612	16120064	KEY WASHER
107-1	11070036	LINE GUARD	613	16130007	COMPRESSION SPRING
108	11080018	HANGER	700	17000094	DRIVE GEAR
108-1	11080030	THE PROTECTION COVER OF REELS LUG	700-1	17000092	DRIVE GEAR
114	11140005	CLAMP	701	17010264	DRIVE GEAR SHAFT
115	11150006	WUNG SCREW	702	17020058	PINION GEAR
116	11160003	WING NUT	702-1	17020070	PINION GEAR
117	11170002	RETAINER NUT	717	17170004	MAIN SHAFT PIN
200	12001780	MAIN SIDE PLATE	718	17180208	MAIN SHAFT
201	12010027	ANTI-RE PAWL	723	17230009	SILENT SPRING
203	12030004	CONTROL PIN	913	19130002	SPRING WASHER
204	12040002	COMPRESSION SPRING	19000004	19000004	E RETAINER
204-2	12040006	COMPRESSION SPRING	29000001	29000001	E RETAINER
204-3	12040011	COMPRESSION SPRING	0910099	0910099	BALL BEARING
205	12050033	DECORATION PLATE	0910459	0910459	BALL BEARING
206	12060002	LEVER DRAG STOPPER CAP	0910445	0910445	BALL BEARING
207	12070075	HOLDED PLATE	0910460	0910460	BALL BEARING
208	12080082	SIDE PLATE COVER	0910409	0910409	BALL BEARING
215	12150022	HOLD PLATE BUSHING	0920207	0920207	WASHER
215-1	12150026	HOLD PLATE BUSHING	0920426	0920426	WASHER
217	12170014	ANTI-RE PAWL SPRING	0920411	0920411	WASHER
217-1	12170018	ANTI-RE PAWL SPRING	0920319	0920319	WASHER
300	13000962	VICE SIDE PLATE	0920481	0920481	WASHER
303	13030068	CLICK KNOB	09201000	09201000	WASHER
304	13040019	CLICK PAWL	0920490	0920490	WASHER
305	13050014	CLICK PAWL SPRING	0920218	0920218	WASHER
311	13110078	SIDE PLATE COVERS	0920503	0920503	WASHER
400	14000849	SPOOL	0920506	0920506	WASHER
401	14010036	CLICK GEAR	0920510	0920510	WASHER
402	14020011	LINE HOLDER	0920154	0920154	WASHER
404	14040012	PRESSURE LOAD BLOCK	0920004	0920004	WASHER
405	14050031	SPOOL COVER	0920263	0920263	WASHER
406	14060006	BUSHING	0930003	0930003	SCREW
500	15000347	HANDLE ASSY.	0930044	0930044	SCREW
501	15010010	HANDLE NUT	0930048	0930048	SCREW
507	15070013	DRIVE GEAR TRASMISSION PIN	0930668	0930668	SCREW
507-1	15070035	PUSH BUTTON	0930651	0930651	SCREW
507-2	15070034	PUSH BUTTON	0930646	0930646	SCREW
508	15080002	PUSH BUTTON SPRING	0930614	0930614	SCREW
513	15130025	HANDLE COVER	0930469	0930469	SCREW
515	15150002	HANDLE SCREW	09301052	09301052	SCREW
516	15160029	HANDLE NUT RETAINER	0930211	0930211	SCREW
517	15170015	DRIVE GEAR PIN	0930196	0930196	SCREW
517-1	15170004	TRANSMISSION PIN	09301130	09301130	SCREW
600	16000101	CAST CONTROL CAP	09301115	09301115	SCREW
601	16010004	DRAG NUT	09301256	09301256	SCREW
602	16020049	ADIUST BLOCK	0940056	0940056	O RING
605	16050131	LEVER DRAG ASSY			