



AZORES-8000 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21004243	MAIN BODY	611	26110039	EARED WASHER
105	21056573	PINION BEARING FIXED PLATE	612	26120120	KEY WASHER
105-1	21056572	PINION BEARING FIXED PLATE	612-1	26120126	KEY WASHER
105-2	21056569	PINION BEARING FIXED PLATE	612-6	26120127	KEY WASHER
105-3	21056570	PINION BEARING FIXED PLATE	700	27002041	DRIVE GEAR
116	21160005	HOLDED PLATE	702	27020763	PINION GEAR
200	22004480	SIDE PLATE	705	27050164	TRANSMISSION GEAR
201	22010722	SIDE PLATE DECORATION	708	27080144	OSCILLATING SLIDER
300	23005044	ROTOR	718	27180761	MAIN SHAFT
301	23012078	BAIL ARM	722	27220043	CLICK GEAR WASHER
304	23042693	BAIL ARM COVER	804	28040052	ANTI-RE LEVER PIN
307	23071777	BAIL HOLDER	808	28080038	RATCHET
309	23090036	BAIL ARM SUPPORT PIN	809	28090034	SILENT SPRING
310	23100082	COMPRESSION SPRING	0910565	0910565	ONE WAY BEARING
313	23134321	BAIL WIRE ASSY.	0910535	0910535	BALL BEARING
315	23150022	LINE ROLLER	0910563	0910563	BALL BEARING
317	23170010	LINE ROLLER WASHER	0910018	0910018	BALL BEARING
318	23180008	ROTOR NUT	0910271	0910271	BALL BEARING
400	240015255	SPOOL ASSY.	0920170	0920170	WASHER
405	24050031	DRAG WASHER RETAINER	0920118	0920118	WASHER
405-1	24050012	DRAG WASHER RETAINER	0920352	0920352	WASHER
405-2	24050058	DRAG WASHER RETAINER	0920563	0920563	WASHER
406	24060037	SPOOL CLICK PAWL	0920571	0920571	WASHER
406-1	24060019	SPOOL CLICK PAWL	09301400	09301400	SCREW
406-2	24060024	SPOOL CLICK PAWL	09301404	09301404	SCREW
407-2	24070014	EXTENSION SPRING	0930477	0930477	SCREW
409	24090006	CLICK PAWL FIX PIN	09301387	09301387	SCREW
412	24120056	SPOOL BUSHING	09301407	09301407	SCREW
413	24130012	WATERPROOF RETAINER	09301401	09301401	SCREW
500	25006008	HANDLE ASSY.	09301394	09301394	SCREW
513	25130864	HANDLE CAP	0930429	0930429	SCREW
600	26003783	DRAG KNOB ASSY.	09301403	09301403	SCREW
610	26100126	DRAG WASHER	09301399	09301399	SCREW
610-1	26100122	DRAG WASHER	0930605	0930605	SCREW