



Fisker-2500 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21004231	Main body	700	27000318	Drive gear
105	21050012	Pinion bearing fixed plate	702	27020907	Pinion gear
105-1	21056571	Pinion bearing fixed bushing	705	27050099	Transmission gear
108	21087126	Cap	708	27080096	Oscillating slider
200	22004470	Side plate	716	27160008	Oscillation slider plate
201	22010041	Side plate decoration	718	27180703	Main shaft
201-1	22010042	Main body decoration	719	27190025	Click gear
201-2	22010013	Side plate decoration	722	27220009	Click gear washer
201-3	22010015	Main body decoration	800	28000333	Anti-reverse/anti-re lever
300	23005105	Rotor	800-1	28000324	Anti-reverse/anti-re lever
301	23012070	Bail arm	801	28010024	Anti-re lever spring
304	23042760	Bail arm cover	0910648	0910648	Ball bearing
305	23050141	Kick lever	0910039	0910039	Ball bearing
306	23061072	Bail holder cover	0910049	0910049	Ball bearing
307	23071782	Bail holder	0910091	0910091	Ball bearing
309	23090002	Bail arm slider	0920310	0920310	Washer
310	23100005	Compression spring	0920376	0920376	Washer
313	23131498	Bail wire assy.	0920154	0920154	Washer
315	23150011	Line roller	0930433	0930433	Screw
316	23160002	Line roller bushing	0930541	0930541	Screw
318	23180005	Rotor nut	0930471	0930471	Screw
400	240015283	Spool assy.	09301252	09301252	Screw
405	24050042	Drag washer retainer	0930209	0930209	Screw
407	24070009	Extension spring	0930044	0930044	Screw
500	25006012	Handle assy.	09301462	09301462	Screw
504	25040004	Handle screw cap washer	0930544	0930544	Screw
513	25130866	Handle cap	09301265	09301265	Screw
600	26003764	Drag knob assy.	0930307	0930307	Screw
610	26100015	Drag washer	0930429	0930429	Screw
611	26110005	Eared washer	0930838	0930838	Screw
612	26120007	Key washer	0930663	0930663	Screw
612-3	26120032	Key washer			