



Fisker-3000 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21004233	MAIN BODY	700	27000322	DRIVE GEAR
105	21050027	PINION BEARING FIXED PLATE	702	27020822	PINION GEAR
105-1	21050036	PINION BEARING FIXED BUSHING	705	27050105	TRANSMISSION GEAR
108	21087127	CAP	708	27080095	OSCILLATING SLIDER
200	22004472	SIDE PLATE	716	27160007	OSCILLATION SLIDER PLATE
201	22010059	SIDE PLATE DECORATION	718	27180705	MAIN SHAFT
201-1	22010060	MAIN BODY DECORATION	719	27190025	CLICK GEAR
201-2	22010029	SIDE PLATE DECORATION	722	27220009	CLICK GEAR WASHER
201-3	22010031	MAIN BODY DECORATION	725	27250020	TRANSMISSION GEAR BUSHING
300	23005031	ROTOR	800	28000242	ANTI-REVERSE/ANTI-RE LEVER
301	23012071	BAIL ARM	800-1	28000322	ANTI-REVERSE/ANTI-RE LEVER
304	23042761	BAIL ARM COVER	801	28010024	ANTI-RE LEVER SPRING
305	23050146	KICK LEVER	0910495	0910495	BALL BEARING
306	23061073	BAIL HOLDER COVER	0910039	0910039	BALL BEARING
307	23071783	BAIL HOLDER	0910049	0910049	BALL BEARING
309	23090002	BAIL ARM SLIDER	0910091	0910091	BALL BEARING
310	23100065	COMPRESSION SPRING	0920540	0920540	WASHER
313	23131499	BAIL WIRE ASSY.	0920355	0920355	WASHER
315	23150011	LINE ROLLER	0920376	0920376	WASHER
316	23160002	LINE ROLLER BUSHING	0920154	0920154	WASHER
317	23170010	LINE ROLLERWASHER	0930044	0930044	SCREW
318	23180005	ROTOR NUT	0930575	0930575	SCREW
400	240015286	SPOOL ASSY.	0930171	0930171	SCREW
405	24050042	DRAG WASHER RETAINER	09301252	09301252	SCREW
407	24070009	EXTENSION SPRING	0930209	0930209	SCREW
500	25006014	HANDLE ASSY.	0930055	0930055	SCREW
504	25040004	HANDLE SCREW CAP WASHER	0930471	0930471	SCREW
513	25130866	HANDLE CAP	0930544	0930544	SCREW
600	26003764	DRAG KNOB ASSY.	09301265	09301265	SCREW
610	26100015	DRAG WASHER	0930643	0930643	SCREW
611	26110005	EARED WASHER	0930964	0930964	SCREW
612	26120006	KEY WASHER	0930838	0930838	SCREW
612-1	26120054	KEY WASHER	0930639	0930639	SCREW
612-2	26120007	KEY WASHER			