



**HX-4000H PARTS LIST**

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21003989	MIAN BODY	612-1	26120054	KEY WASHER
105	21050027	PINION BEARING FIXED PLATE	612-2	26120007	KEY WASHER
105-1	21050036	PIN. BEARING FIXED PLATE	700	27002036	DRIVE GEAR
108	21081451	CAP	702	27020757	PINION GEAR
200	22004319	SIDE PLATE	705	27050150	TRANSMISSION GEAR
201	22010419	MAIN BODY DECORATION	708	27080127	OSCILLATING SLIDER
201-1	22010420	SIDE PLATE DECORATION	716	27160007	OSCILLATION SLIDER PLATE
201-2	22010445	MAIN BODY DECORATION	718	27180735	MAIN SHAFT
201-3	22010446	SIDE PLATE DECORATION	719	27190025	CLICK GEAR
300	23004851	ROTOR	722	27220009	CLICK GEAR WASHER
301	23011926	BAIL ARM	725	27250020	TRANSMISSION GEAR BUSHING
304	23042610	BAIL ARM COVER	800	28000241	ANTI-REVERSE/ANTI-RE LEVER
305	23050146	KICK LEVER	800-1	28000322	ANTI-REVERSE/ANTI-RE LEVER
307	23071531	BAIL HOLDER	801	28010024	ANTI-RE LEVER SPRING
309	23090002	BAIL ARM SLIDER	0910495	0910495	BALL BEARING
310	23100067	COMPRESSION SPRING	0910256	0910256	BALL BEARING
313	23131574	BAIL WIRE ASSY.	0910054	0910054	BALL BEARING
315	23150029	LINE ROLLER	0910278	0910278	BALL BEARING
317	23170013	LINE ROLLERWASHER	0910221	0910221	BALL BEARING
317-1	23170024	LINE ROLLER WASHER	0920540	0920540	WASHER
318	23180005	ROTOR NUT	0920376	0920376	WASHER
400	240014588	SPOOL ASSY.	0920154	0920154	WASHER
405	24050042	DRAG WASHER RETAINER	09301377	09301377	SCREW
407	24070010	EXTENSION SPRING	0930575	0930575	SCREW
412	24120038	SPOOL BUSHING	0930171	0930171	SCREW
413	24130009	WATERPROOF RETAINER	0930209	0930209	SCREW
500	25005783	HANDLE ASSY.	0930438	0930438	SCREW
504	25040004	HANDLE SCREW CAP WASHER	0930471	0930471	SCREW
513	25130830	HANDLE CAP	09301379	09301379	SCREW
600	26003005	DRAG KNOB ASSY.	0930643	0930643	SCREW
610	26100109	DRAG WASHER	09301380	09301380	SCREW
611	26110005	EARED WASHER	09301374	09301374	SCREW
612	26120006	KEY WASHER	0930639	0930639	SCREW