



Sonic Spin 1000 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21004103	MAIN BODY	708	27080096	OSCILLATING SLIDER
102	0910361	BUSHING	716	27160008	OSCILLATION SLIDER PLATE
102-1	0910381	BUSHING	718	27180467	MAIN SHAFT
108	21081489	CAP	719	27190029	CLICK GEAR
200	22004350	SIDE PLATE	722	27220009	CLICK GEAR WASHER
300	23004893	ROTOR	725	27250023	TRANSMISSION GEAR
301	23011960	BAIL ARM	800	28000333	ANTI-REVERSE/ANTI-RE LEVER
304	23042642	BAIL ARM COVER	800-1	28000345	ANTI-REVERSE/ANTI-RE LEVER
305	23050092	KICK LEVER	801	28010024	ANTI-RE LEVER SPRING
307	23071565	BAIL HOLDER	804	28040037	ANTI-RE LEVER PIN
309	23090002	BAIL ARM SLIDER	808	28080031	RATCHET
310	23100048	COMPRESSION SPRING	809	28090017	SILENT SPRING
313	23134033	BAIL WIRE ASSY.	910049	910049	BALL BEARING
315	23150022	LINE ROLLER	0920310	0920310	WASHER
316	23160002	LINE ROLLER BUSHING	0920154	0920154	WASHER
317	23170008	LINE ROLLER WASHER	0930437	0930437	SCREW
318	23180005	ROTOR NUT	0930539	0930539	SCREW
400	240014565	SPOOL ASSY.	0930354	0930354	SCREW
405	24050001	DRAG WASHER RETAINER	0930624	0930624	SCREW
412-1	24120047	SPOOL BUSHING	0930417	0930417	SCREW
500	25005775	HANDLE ASSY.	0930432	0930432	SCREW
513	25130841	HANDLE CAP	0930470	0930470	SCREW
515	25150002	HANDLE SCREW CAP WASHER	0930939	0930939	SCREW
600	26003265	DRAG KNOB	09301264	09301264	SCREW
610	26100015	DRAG WASHER	0930640	0930640	SCREW
612	26120003	KEY WASHER	0930428	0930428	SCREW
612-3	26120032	KEY WASHER	0930636	0930636	SCREW
700	27000318	DRIVE GEAR	0930836	0930836	SCREW
702	27020341	PINION GEAR	0930662	0930662	SCREW
705	27050098	TRANSMISSION GEAR			