



**Sonic Spin 4000 PARTS LIST**

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21004104	MAIN BODY	708	27080095	OSCILLATING SLIDER
102	0910361	BUSHING	716	27160007	OSCILLATION SLIDER PLATE
102-1	0910381	BUSHING	718	27180468	MAIN SHAFT
108	21081490	CAP	719	27190029	CLICK GEAR
200	22004351	SIDE PLATE	722	27220009	CLICK GEAR WASHER
300	23004896	ROTOR	722-1	27220037	CLICK GEAR WASHER
301	23011961	BAIL ARM	725	27250013	TRANSMISSION GEAR BUSHING
304	23042645	BAIL ARM COVER	800	28000242	ANTI-REVERSE/ANTI-RE LEVER
305	23050089	KICK LEVER	800-1	28000322	ANTI-REVERSE/ANTI-RE LEVER
307	23071566	BAIL HOLDER	801	28010024	ANTI-RE LEVER SPRING
309	23090002	BAIL ARM SLIDER	804	28040044	ANTI-RE. PAWL
310	23100001	COMPRESSION SPRING	808	28080029	RATCHET
313	23131058	BAIL WIRE ASSY.	809	28090017	SILENT SPRING
315	23150022	LINE ROLLER	0910049	0910049	BALL BEARING
316	23160002	LINE ROLLER BUSHING	0920310	0920310	WASHER
318	23180005	ROTOR NUT	0920376	0920376	WASHER
400	240014571	SPOOL ASSY.	0920151	0920151	WASHER
405	24050001	DRAG WASHER RETAINER	0930417	0930417	SCREW
500	25005777	HANDLE ASSY.	0930574	0930574	SCREW
513	25130841	HANDLE CAP	0930170	0930170	SCREW
515	25150002	HANDLE SCREW CAP WASHER	0930624	0930624	SCREW
600	26003266	DRAG KNOB	0930437	0930437	SCREW
610	26100015	DRAG WASHER	0930470	0930470	SCREW
611	26110004	EARED WASHER	0930432	0930432	SCREW
612	26120004	KEY WASHER	09301264	09301264	SCREW
612-1	26120054	KEY WASHER	0930662	0930662	SCREW
612-2	26120003	KEY WASHER	0930966	0930966	SCREW
700	27000322	DRIVE GEAR	0930215	0930215	SCREW
702	27020340	PINION GEAR	0930836	0930836	SCREW
705	27050107	TRANSMISSION GEAR	0930638	0930638	SCREW