



Sonic Spin 5000 PARTS LIST

KEY NO	PARTS NO	PARTS NAME	KEY NO	PARTS NO	PARTS NAME
100	21004105	MAIN BODY	708	27080097	OSCILLATING SLIDER
102	21020002	DRIVE GEAR BUSHING	716	27160009	OSCILLATION SLIDER PLATE
108	21081491	CAP	718	27180484	MAIN SHAFT
200	22004352	SIDE PLATE	719	27190029	CLICK GEAR
300	23004897	ROTOR	722	27220009	CLICK GEAR WASHER
301	23011962	BAIL ARM	722-1	27220037	CLICK GEAR WASHER
304	23042646	BAIL ARM COVER	725	27250020	TRANSMISSION GEAR BUSHING
305	23050099	KICK LEVER	800	28000256	ANTI-REVERSE/ANTI-RE LEVER
307	23071567	BAIL HOLDER	800-1	28000330	ANTI-REVERSE/ANTI-RE LEVER
309	23090030	BAIL ARM SUPPORT PIN	801	28010039	ANTI-RE LEVER SPRING
310	23100058	COMPRESSION SPRING	804	28040036	ANTI-RE LEVER PIN
313	23131037	BAIL WIRE ASSY	808	28080028	RATCHET
315	23150022	LINE ROLLER	809	28090018	SILENT SPRING
316	23160002	LINE ROLLER BUSHING	0910096	0910096	BALL BEARING
318	23180001	ROTOR NUT	0920431	0920431	WASHER
400	240014573	SPOOL ASSY.	0920376	0920376	WASHER
405	24050001	DRAG WASHER RETAINER	0920150	0920150	WASHER
412-1	24120045	SPOOL BUSHING	0930417	0930417	SCREW
500	25005779	HANDLE ASSY.	0930043	0930043	SCREW
513	25130841	HANDLE CAP	0930574	0930574	SCREW
515	25150002	HANDLE SCREW CAP WASHER	0930170	0930170	SCREW
600	26003266	DRAG KNOB	09301001	09301001	SCREW
610	26100015	DRAG WASHER	0930470	0930470	SCREW
611	26110037	EARED WASHER	09301273	09301273	SCREW
612	26120004	KEY WASHER	0930662	0930662	SCREW
612-1	26120056	KEY WASHER	0930762	0930762	SCREW
700	27000328	DRIVE GEAR	0930215	0930215	SCREW
702	27020439	PINION GEAR	0930826	0930826	SCREW
705	27050102	TRANSMISSION GEAR	0930638	0930638	SCREW